


Inteligentní ultrazvukový domácí čistič zubů s TRUESONIC

Uživatelská příručka
Product introduction



Děkujeme za výběr a důvěru

Představení produktu

Zdraví začíná u zubů. Děkujeme, že jste si vybrali náš inteligentní ultrazvukový čistič zubů Truesonic. Je speciálně navržen pro domácí použití. Truesonic má stabilní výkon s řadou funkcí. Účinně odstraňuje zubní plak, zubní kámen, skvrny ze zubů a odstraněním tvrdého zubního kamene předchází onemocnění dásní. Tento multifunkční odstraňovač zubního plaku využívá pokročilé vibrace k odstranění zubního kamene a pigmentace z vašich zubů. Obsluha je jednoduchá, pohodlná, rychlá a efektivní.

Důležité bezpečnostní pokyny

- Před použitím výrobku si pečlivě přečtěte tento návod A UCHOVEJTE JEJ PRO BUDOUCÍ POUŽITÍ.
- Při použití vždy přiložte špičku na povrch zubu. Vyvarujte se zbytečného kontaktu špičky s měkkými tkáněmi, jako jsou dásně, sliznice nebo kůže.
- Vibrace ucítíte až při kontaktu se zubem. Při kontaktu s dásní se čistič automaticky vypne.
- Špička se během čištění nesmí dotýkat keramické protézy, plomby ani jakékoliv výplně zubu. Mohlo by dojít k poškození špičky. Nepoužívejte přístroj jinou metodou, než je popsána v tomto návodu.
- Kovová hlavice čističe zubů je vyměnitelná.
- Udržujte čistič zubů v dostatečné vzdálenosti od očí.
- V případě poruchy, prosím přestaňte používat.
- Tento výrobek není hračka. Nenechte ho používat své děti.
- Zakázáno pacientům s kardiostimulátorem.
- Pacienti s onemocněním srdce, těhotné ženy a děti by měli být opatrní.
- Nevystavujte výrobek přímému slunečnímu záření, měl by být skladován v 10° až 40°C ve vnitřním prostředí.
- Výrobek sami nerozebírejte.
- Nepoužívejte výrobek během nabíjení.
- V případě problémů s kvalitou produktu kontaktujte zákaznický servis obchodu, kde jste tento produkt zakoupili.

Princip fungování produktu

Tento čistič pracuje na principu, který převádí elektrickou energii na energii ultrazvukových vibrací. Stisknutím tlačítka napájení zapnete zařízení, upravte výkon pomocí tlačítek režimů a začnete čistit požadovaná místa na zubech. Vysoké vibrace slouží k rozdrncení zubního kamene, odstranění odolných zubních skvrn a uvolněného zubního kamene.


Záležitosti vyžadující pozornost

1. Pokud máte onemocnění parodontu, poraďte se před použitím se svým zubním lékařem.
2. Může dojít ke krvácení i v případě zdravé dásně.
3. Pokud krvácení z dásní přetrvává, což může být způsobeno defekty dásní, jako je periodontální onemocnění, přerušete používání a poraďte se se svým zubním lékařem.
4. V procesu čištění zubů nezůstávejte pracovním hrotem dlouho na povrchu zubů.
5. Po spuštění přístroje není slyšet žádný zvuk hrotu. Zvuk ultrazvuku uslyšíte až při kontaktu se zubem.
6. Nenamáčejte do vody nebo kapaliny.
7. Před a po použití udržujte stroj čistý.
8. Pracovní hrot musí být při použití utažen.
9. Neohýbejte ani neobrušujte pracovní hrot.
10. Nekomlepejte ani neškrábejte do rukojeti.
11. Po použití stroj osušte a uchovávejte jej v suchém a chladném prostředí.
12. Během používání zařízení netahejte za napájecí kabel, aby nedošlo k oddělení rukojeti od stroje.

Čištění a údržba

1. Nevkládejte ani nepouštějte výrobek do jiných kapalin ani do nich.
2. Se zařízením je třeba zacházet opatrně a skladovat jej na suchém místě.
3. Nemíchejte s toxickými, žíravými, hořlavými a výbušnými materiály.
4. Po každém čištění si důkladně vypláchněte ústa.
5. Umyjte kovovou hlavici pod čistou tekoucí vodou.
6. Otřete tělo čističe zubů.


Popis produktu




Používání

1. Před použitím se ujistěte, že je čistič plně nabitý. Úplné nabití trvá přibližně 2 hodiny.
2. Pokud nabíjíte čistič zubů poprvé nebo jste jej delší dobu nepoužívali (déle než 3 měsíce), může úplné nabití vyžadovat více času.
3. Vyberte vhodný hrot a nainstalujte jej ve směru hodinových ručiček. **NEPOUŽÍVEJTE** silné otáčení, aby nedošlo k poškození.
4. Stiskněte tlačítko pro spuštění přístroje ON a zapněte režim SOFT pro normální čištění. Rozsvítí se kontrolka režimu spuštění a LED světlo na předním konci rukojeti, což znamená, že přístroj běží.
5. Strana konce špičky se umístí na zub tak, aby byl pohyb špičky rovnoběžný s povrchem zubu.
6. Těžko odstranitelný zubní kámen však může vyžadovat vyšší nastavení výkonu v režimu COMFORT a STRONG.
7. Ujistěte se, že během čištění udržujete kontakt špičky s povrchem zubu. Špičkou stále pomalu pohybujte tam a zpět a nechte práci na přístroji. Používejte krátké a dlouhé tahy, aby se celý povrch každého zubu vyčistil.
8. Nikdy nesetrávejte na jednom místě déle než 5s, aby nedošlo k zahřátí ošetřovaného místa.
9. Pozor: Při čištění zubů nevyvíjejte velkou sílu na jednom místě!
10. Přístroj je náchylný na poškození vnitřních a vnějších součástí způsobených pádem či nesprávným zacházením.
11. Používejte přístroj s navlhčenými ústy.
12. Pokud vám během používání ústa vyschnou, vypláchněte si je.
13. Při použití na vnitřní straně zubu použijte zubní zrcátko.
14. Detekce nízkého napětí. Alarm bliká když je napětí baterie nižší než 3V.
15. Po použití dlouze stiskněte tlačítko OFF a vypněte napájení. Zařízení má přednastavenou funkci automatického vypnutí po 10 minutách, aby se zabránilo ochraně proti přehřátí.

Hroty



Hrot 1 je tenký, používá se k odstranění zubního kamene a mezizubní čištění.




Hrot 2 je širší, slouží k odstranění velkých zubních kamenů a pigmentace na zubech.



- Dezinfikujte pracovní hrot horkou vodou s vysokou teplotou před použitím.
- Abyste předešli křížové infekci, nesdílejte pracovní hrot s dalšími lidmi.
- Frekvence přístroje je různá, vyberte si prosím správný pracovní režim.
- Použijte pracovní hrot správně, jak je uvedeno výše.

Jak používat hroty


Pracovní hrot se jemně svisle dotýká zubů a pohybuje se nahoru a dolů, stejně jako doleva a doprava. Upravte dobu používání každé části podle stavu zubů.




Nečistoty na povrchu zubů




Hranice mezi dásní a zubem




Mezizubní mezery





Nečistoty v nerovnostech zubů



Nečistoty na zadní straně zubů




Použijte ústní zrcátko, při čištění zadní části zubů




Výměna pracovního hrotu




Pokud je spojení uvolněné, vibrace nelze přenášet správně. Použijte instalační klíč a ujistěte se, že pracovní hrot je připojen pevně. K rozebrání nepoužívejte jiné nástroje. Můžete způsobit poruchu nebo poškození.




Potvrďte pozici A



Vložte klíč do polohy A



Otočte hlavu proti směru hodinových ručiček pomocí klíče k oddělení pracovního hrotu a dokončete demontáž.




Preventivní opatření

Vyvarujte se příliš těsnému utažení, které by mohlo způsobit poškození.

Údržba



Nepoužívejte ředidla, benzen a rozpouštědla, chemikálie, nebo čisticí prášky.



Tělo přístroje může být přímo omyté vodou a špínu lze otřít pomocí hadříku.

Product introduction

Health starts with teeth. Thank you for choosing our LED household intelligent ultrasonic household tooth cleaner. The LED lamp household intelligent ultrasonic household tooth cleaner is specially designed for family users. Through innovative design, the complex structure of the original tooth cleaner is changed into an intelligent chip integrated circuit, and the advanced intelligent frequency stabilization design concept is adopted. It has stable performance and strong applicability, and can cooperate with a variety of functions. The whole process of tooth cleaning is completed under the control of microprocessor, which ensures the stable output of power and can effectively remove dental calculus, smoke stains, plaque and tea stains. The operation is simple, convenient, fast and efficient.

How to use it safely

- If you use any improper method that is not described in this instruction manual or is not used correctly, please stop using it. In case of failure, please stop using.
- This product is not a toy. Please don't let your child use it directly.
- It is forbidden for patients with pacemaker.
- Patients with heart disease, pregnant women and children should be cautious.
- Please do not put the product in direct sunlight, it should be stored in 10° to 40°C indoor environment.
- Please don't disassemble, transform or bend this product by yourself.
- In case of product quality problems, please contact the customer service of the store where you purchased this product.

Product features

1. This product is designed for family, simple, fast and efficient.
2. UHF vibration, gentle, comfortable, enhanced three mode adjustable.
3. 10 minutes automatic stop work protection design, stop work after the LED light off.
4. Integrated design, head LED lighting, clear observation of oral conditions.
5. The ultrasonic transducer is made of aviation titanium alloy.

Product principle

The high-frequency electric pulse wave is generated by the electronic oscillation circuit, amplified to a certain intensity, and transmitted to the transducer, which converts the electric energy into mechanical energy, and stimulates the working tip to produce the same frequency vibration, so as to achieve the purpose of crushing the dental calculus and sweeping away the stubborn dental stains and loose tartar. The ion is produced by the ion generator, and the ion is produced by holding the ion connecting ring. The negative ions are transmitted to the teeth, and the tooth stains are loose and separated from the teeth by using the principle of negative ion exclusion.

Matters needing attention

1. When the ultrasonic working tip touches the teeth, it makes a beeping sound, which is the normal working state.
2. If you have periodontal disease, consult your dentist before use.
3. If it is on the boundary of the gingiva, gingival bleeding may occur even in the case of healthy gingiva.
4. If gum bleeding persists, which may be due to gum defects such as periodontal disease, discontinue use and consult your dentist.
5. In the process of tooth washing, do not stay on the surface of teeth for a long time with the working tip. To remove the calculus and stains of stubborn teeth, please use the working tip to remove them.
6. When working without water, do not touch the gums for a long time. Long time contact with the gums may bum the gums.
7. After the machine is started, there is no peak sound at the working point. If there is a peak sound, it is a normal phenomenon, you can re install the working tip or tighten the working tip.
8. Even if it is not used directly with the front end of the head, a weak current will be felt due to the ion output when treating the area near the parts with tooth decay, gold crown or silver crown. In this case, please do not touch the ion connection ring, only use the ultrasonic output for treatment, and the ion output will not be transmitted to the teeth.


Cleaning and maintenance

1. Do not put or drop the product into or into other liquids.
2. The equipment should be handled with care and stored in a dry place.
3. Do not mix with toxic, corrosive, flammable and explosive materials.

Matters needing attention

1. Do not soak in water or liquid.
2. Keep the machine clean before and after use.
3. The working tip must be tightened when using.
4. Power on for the first time to use, first run for 2 ~ 3 seconds, stop for 1 second, such operation several times, easy to work head in the best state.
5. Do not bend or grind the work tip.
6. Do not knock or scrape the handle.
7. Please dry the machine after use and keep it in a dry and cool environment.
8. Do not pull the power cord during the use of the equipment, so as not to cause the handle to separate from the machine.


Popis produktu




How to operate

1. Make sure the cleaner is fully charged before use.
2. Press the on key to start the machine, turn on the light and enter the soft gear.
At the same time, turn on the negative ion and ultrasonic mode. Press the on key again, the negative ion remains unchanged, and the ultrasonic enters the comfort gear. And so on, there are three gears in total. It is suggested to start from the low gear and gradually increase the gear after adaptation.
 1. Soft
 2. comfort
 3. strong
3. Select a suitable working point and install it clockwise on the main engine with a small wrench. DO not use strong rotation, so as not to damage the interface. First, open the appropriate gear and vibrate the tooth stone with the metal head. Then, when operating on the tooth stone, scrape it with a little strength and try more times. Because the tooth stone is stubborn, a little more patience will make it easier to master the method.
4. Press C on and off, the mode light shines, and the LED light at the front end of the handle lights up, indicating that the machine is running.
5. When the machine works normally, the vibration frequency is very fast. When cleaning teeth, it only needs light contact and repeated movement at a certain speed to clear teeth stones.
Caution: DO not apply partial force or stay too long when cleaning teeth!
6. When off, please press the on key, and unplug the power plug after the LED light is off.
7. The machine is a precision equipment. Please avoid damage to internal and external components caused by fling, touching and dropping.
8. Brush head is to clean the teeth after calculus, can not be used as an electric toothbrush.
9. Low voltage detection, when the battery voltage is lower than 3V, flash light alarm.
10. After use, long press the open key, the power off, the equipment preset 10 minutes automatic shutdown function, to prevent overheating protection.

Introduction to work tips



Tip 1 is thin, used to remove calculus and tooth smoke stains on gingiva.




Tip 2 is wider, used to remove large stones and smoke stains on the neck and lingual side of the supragingival teeth.

- Please steam, soak in alcohol and disinfect the working tip by high temperature and high pressure before use.
- In order to prevent cross infection, do not share the work tip with many people.
- The machine frequency is different, please choose the right working point.
- Please use the work tip correctly as shown above.


How to use work tips

The work tip gently touches the teeth vertically and moves to the top and bottom as well as left and right. Please adjust the use time of each part according to the condition of teeth.


⚠ Please do not use the surface of the work tip without tooth dirt.




Tooth surface dirt




Boundary between gum and tooth




Interdental gap





Dirt from uneven teeth



Dirt on the back of teeth



Please use mouth glasses when treating the back of teeth




How to change the work tip


The orientation of the work tip may be different but as long as it is firmly mounted on it, it can be used in any direction.




If the connection is loose, the output cannot be transmitted correctly, so make sure the work tip is tightly connected and use the wrench kit for the work tip installation. Please do not use other tools to disassemble the sample plate, which may cause failure or damage.




Confirm position A



Insert the wrench in position A



Rotate the head counter clockwise with a wrench to separate the working tip and complete the disassembly.




Preventive measure

Avoid over tight assembly, resulting in damage to the interface.

How to maintain



Please do not use diluents, benzene and solvents, chemicals, scrubbing powder.



The main body can be directly washed with water, and the dirt on the main body can be wiped with a rag.

